## VITTORIA H



Cultivator with 30x30 spiral spring and cage roller


55cm RH side inter-row blade with quick tractor couplings and mechanical emergency blade return Bulldozer-like tilling spur

4,5 - 21 - 26 cm ploughshare (to specify during the order)

Rear roller mechanical adjustment

Model	CODE	Tests	(0	TII		<b>T</b>	Kg.
Vittoria H 3	0727	30 - 40	3	53	85	20	380
Vittoria H 4	0728	30 - 40	4	53	105	20	395
Vittoria H 5	0729	30 - 40	5	53	135	20	410
Vittoria H 6	0730	40 - 70	6	53	150	20	425

Vittoria H 7	0731	40 - 70	7	53	165	20	450
Vittoria H 8	0732	60 - 80	8	53	190	20	475
Vittoria H 9	0733	60 - 80	9	53	205	20	500



## **Optional**

- CODE 1290 Type H kit including tank, oil, filter, pump, multiplier and single heat exchanger kit with thermostat
- CODE 0659 Hydraulic roller adjustment with 2 quick tractor couplings
- CODE 1328 RH and LH set 3 kit adapters in boron steel complete of reversible chisel and laterals fins
- CODE 1329 Set 4 kit adapters in boron steel complete of reversible chisel and RH and LH laterals fins
- CODE 1330 Set 5 kit adapters in boron steel complete of reversible chisels and RH and LH laterals fins
- CODE 1331 Set 6 kit adapters in boron steel complete of reversible chisels and RH and LH laterals fins
- CODE 1332 Set 7 kit adapters in boron steel complete of reversible chisels and RH and LH laterals fins
- CODE 1333 Set 8 kit adapters in boron steel complete of reversible chisels and RH and LH laterals fins
- CODE 1334 Set 9 kit adapters in boron steel complete of reversible chisels and RH and LH laterals fins
- CODE 0024 250x100 mm pair of depth wheels with brackets (cannot be installed on Futura H 3 5S 5 and Basic 3 4)
- CODE 0698 RH hydraulic inter-row inclination with 2 quick tractor couplings. Dimension cm 6,5
- CODE 1048 RH inter-row hydraulic ascent and descent system stroke 20 cm PATENTED, with 2 quick tractor couplings. Dimension cm 10
- CODE 0982 Blade with clod breaker, fin and feeler pin cm 45 (additionally at the standard blade)
- CODE 0695 Blade with clod breaker, fin and feeler pin cm 65 (additionally to standard blade)

- CODE 1160 - RH non-stop feeler pin holder
- CODE 1085 - RH oscillating feeler pin holder adjustable in height
- CODE 1050 - RH stump cleaner for inter-row kit (applicable simultaneously at following inter-row tools: inter-row blade, plant lifting ploughshare, circular cutter, rotary plant lifter and traction disk set)
- CODE 0483 - RH sled for terrain with stones or superficial roots
- CODE 1187 - RH 45 cm inter-row plant lifting ploughshare
- CODE 1268 - RH 55 cm inter-row plant lifting ploughshare
- CODE 1266 - Universal no traction adjustable rounded tiller disc
- CODE 0488 - RH no traction bulldozer-disk diam. 320
- CODE 1264 - Universal no traction adjustable ridger bit disc
- CODE 1312 - Universal no traction adjustable serrated ridger 2-discs complete with cleaner on first disk

Print this page